# Neutral Beam Atomic Data Used in Analysis Codes on DIII-D and NSTX-U

B.A. Grierson, Princeton Plasma Physics Laboratory Second RCM of the Neutral Beams CRP IAEA Headquarters Vienna, Austria February 18, 2019 D. P. Stotler<sup>1</sup>, D. Liu<sup>2</sup>, M. Gorelenkova<sup>1</sup>, W. W. Heidbrink<sup>2</sup>, F. M. Levinton<sup>3</sup>, H. Yuh<sup>3</sup>, R.E. Bell<sup>1</sup>


<sup>1</sup>Princeton Plasma Physics Lab, <sup>2</sup>U. California Irvine, <sup>3</sup>Nova Photonics






### The Goal of this Presentation is to Provide the Atomic Data, Use Cases, Validation and Challanges on Existing US Tokamaks

- This CRP aims to provide evaluated and recommended data for the principal atomic processes of heating and diagnostic neutral beams in fusion plasma<sup>1</sup>
- The tokamaks should validate the recommended data through careful experimental testing and assessment of measurement uncertainty



### First Meeting<sup>1</sup> Previewed NSTX-U and DIII-D Configuration and Codes Used for Analysis and Simulation

- Neutral beam geometry and range of typical operating plasma conditions
- Introduction to TRANSP/NUBEAM
- Introduction to FIDASIM
- CHERS layout on NSTX-U and DIII-D
- MSE systems






#### This Presentation Covers ...

- Review of procedure for tokamak impurity density analysis
- Rate coefficients used for NSTX-U and DIII-D for carbon
- Validation of carbon rate coefficients
- Atomic data used for NUBEAM and FIDASIM
- Other impurities



# Direct and Local Impurity Density Measurements are Essential for Plasma Transport Studies

- DIII-D and NSTX have graphite first wal and measure fully stripped carbon emission
  - C-VI (8-7) 5290.5 Å
- Low-to-high confinement mode transition displays change in transport
- Accurate measure of impurity density and spatial gradients are essential for basic and advanced tokamak plasma physics
  - Neutral beam deposition, emission
  - Charge exchange from light impurities








# Determining Plasma Ion Density is More Challenging Than the Temperature and Velocity

- Entire optical system must be absolutely calibrated
  - Mirrors, lenses, fiber optic cables, spectrometer and detector
  - Each component could be calibrated individually
  - → Permits replacement of single components during operation
- More convenient to perform a complete assembly; then calibrate the entire system as a whole








# In situ Validation of Rate Coefficients is Challenging and Typically Requires Multiple Redundant Diagnostics


 "Direct" local ion densities from charge-exchange is the ideal end product measurement → Each step has uncertainty






#### Given All of the Uncertainties and Invocation of Novel Calibrations the Rate Coefficients for Carbon do not Appear to Be Egregiously Off

- Tokamak plasma physicist rely on accurate plasma composition/dilution measurements to assess confinement, instabilities, etc...
- Data consistency checks essential  $\rightarrow$  survey spectroscopy, Zeff, CHERS








## Rate Coefficients for C-VI (8-7) for n=1 and n=2 are the Same For DIII-D and NSTX

- A rate coefficient file is provided in the ADAS distribution
  - Black curve in plots
- DIII-D and NSTX staff have re-run ADAS to produce private adf12 files
  - J.M. Munoz-Burgos in 2010
  - V. Soukhanovskii in 2003










#### Rate Coefficients for C-VI (8-7) for n=1 and n=2 are the Same For DIII-D and NSTX

- A rate coefficient file is provided in the ADAS distribution
  - Black curve in plots
- DIII-D and NSTX staff have re-run ADAS to produce private adf12 files
  - J.M. Munoz-Burgos in 2010
  - V. Soukhanovskii in 2003










### However Operation Away From Nominal Conditions Can Reveal Large Discrepancies Between Impurity Density Measured by CXRS


- Sightlines that cross two neutral beams provide opportunity to explore rate coefficients
- Consider one core tangential sightline T7 viewing 30LT and 30RT
  - Same plasma flux surface
- We inject 30LT at its nominal voltage of 81 kV
  - Same voltage as absolute and relative calibrations
- Vary the voltage of 3RT
  - Move down from nominal 75 kV to 50 kV
     Should measure same impurity density!





### However Operation Away From Nominal Conditions Can Reveal Large Discrepancies Between Impurity Density Measured by CXRS

- Carbon density from T7 viewing 30LT at 81 kV is reference
- Carbon density computed from T7 viewing 30RT becomes erroneously high as 30RT voltage is varied from 50-75 kV
- Indicates that rate coefficient or other process is increasing intensity at C-VI (8-7) 5290.5







# A Number of Contributing Factors Could Cause the Anomalously High Calculated Impurity Density

- Rate coefficient could be incorrect at low energy F/H/T of 25/12.5/8.3 keV/amu
  - Ground state n=1 rate small, n=2,... rates become large at low keV/amu
- Neutral beam power/species/geometry could be incorrect<sup>1</sup>
  - Neutral beams are calibrated with water flow calorimetry at few voltages
  - Species mix measurements only available on a few beams<sup>2</sup>
  - Neutral beam divergence may change with pulse as perveance is adjusted<sup>3</sup>
- Background emission becomes large relative to active emission and may require more careful background subtraction to remove contribution
- Other atomic processes such as plume emission, and excited halo neutral donors may become large


All of these processes are being considered and quantified



### Neither DIII-D nor NSTX Have or Use Contributions from n>2 Beam Neutrals for Determining Carbon Density

- Mentioned by D. Stotler at 2017 RCM1
- Previous work on TFTR<sup>1</sup> showed that emission ratios from C-VI 8-7, 14-10, 17-11 indicate population of high-n
- DIII-D has confirmed this measurement
  - More shown on later slides in this presentation on Li-III density

CX spectra obtained by subtracting pre-beam spectrum from post-beam turn-on spectrum.



Assuming fully mixed levels, the TFTR
measurements imply that the n=14 and n=17 levels
are more populated by charge exchange with the
neutral beams that the n=8 level



# Neither DIII-D nor NSTX Include Photoemission from Halo Neutral CX with Impurity Ions

• Beyond direct charge-exchange  $[D_b^{\ 0}(n) + C^{+5}]$  there can be halo neutrals as a source of CX with low energy and n>1  $D_{th}^{\ 0}(n) + C^{+6} \rightarrow D_{th}^{\ +} + C^{+5}(n')$ 

- Conditions most sensitive to this process will be high density plasmas with high plasma purity
  - High density → strong beam attenuation minimizes n<sub>b</sub>
  - High purity → large population of halo neutrals
- ASDEX-Upgrade recently implemented calculations and corrections for this process → Reduces peaking of impurity density profile<sup>1</sup>



#### **Interim Summary**

- Both NSTX and DIII-D use the same rate coefficients for n=1 and n=2 donors for CX onto fully stripped carbon
- This procedure produces reasonable data consistency checks for nominal tokamak operation
  - Carbon is overwhelmingly dominant impurity in most conditions
  - Neutron rates and stored energy in reasonable agreement
  - Bremsstrahlug emission consistent<sup>1</sup>
- There are known shortcomings in existing analysis of unquantified impact
  - Higher n-level donors for CX, multi-step halo neutrals



### TRANSP/NUBEAM and FIDASIM


#### Recommended Settings for NUBEAM Atomic Data Usage

- Tokamaks are now suggested to use full ADAS atomic data for NUBEAM in TRANSP
  - LEV NBIDEP =  $2 \rightarrow All ADAS$  atomic physics
  - NSIGEXC = 3 → Excited states, stopping cross-sections from ADAS 310 (in appendix of D.P. Stotler RCM1)
- In high density plasmas the enhancement to the stopping cross-section from excited states can be significant
- For typical operating voltages and densities the impact on beam heating appears relatively minor





### Comparison of Simple and ADAS Excited States Shows 10-15 % Differences for Moderate DIII-D Density



- DIII-D daily reference shot with
   <n<sub>e</sub> > 5.7 e19
- Compare three TRANSP runs
  - LEV\_NBIDEP=1 (ground), NSIGEXC=1 (simple)
  - LEV\_NBIDEP=2 (ADAS), NSIGEXC=1 (simple)
  - LEV NBIDEP=2 (ADAS), NSIGEXC=3 (ADAS)
- Ground state with simple excitation is the weakest stopping from CX
- All three give comparable total stopping, power flows and neutrons for this moderate density





#### FIDASIM Proton CX Data Includes Higher-n Levels

#### FIDASIM is fully documented <u>online</u>

 Use "equivalence principle" to obtain reverse reactions for data available in ADAS

$$\sigma(n_f \to n_i) = \frac{E_i}{E_f} \frac{n_i^2}{n_f^2} \sigma(n_i \to n_f)$$

- Data from JRS-4105 used to fill out table
- Cross sections summed over m → "spread" out assuming exponential variation with energy difference

H-H Charge Exchange Data Source

		0	78				5	
	n \ m	1	2	3	4	5	6	Total
)	1	ADAS	ADAS	ADAS	ADAS	Spread	Spread	Janev(n=1)
	2	Equivalence	ADAS	ADAS	Spread	Spread	Spread	Janev(n=2)
	3	Equivalence	ADAS	ADAS	ADAS	ADAS	Spread	ADAS/Janev(n=3)
	4	Equivalence	Equivalence	Equivalence	Spread	Spread	Spread	Janev(n=4)
	5	Spread	Equivalence	Equivalence	Spread	Spread	Spread	Janev(n=4)
	6	Spread	Equivalence	Equivalence	Spread	Spread	Spread	Janev(n=4)





### Other Impurities

# DIII-D is Expanding the Use of a Range of Impurities for Charge-Exchange


Recent increased emphasis on impurity transport including installation of laser blow-off by MIT

Some recent impurities that have been used

Nitrogen (Z=7) N-VII(9-8) 5669.0


Rate from ADAS, updated by J.M. Munoz-Burgos


- Fluorine (Z=9) F-IX(10-9) 4796.0
  - Rate from M. O'Mullane July 12 2013
- Neon (Z=10) Ne-X(11-10) 5249.2
  - Rate from ADAS, updated by J.M. Munoz-Burgos
- Aluminum (Z=13) Al-XIII (12-11) 4083.8
  - Rate from M. O'Mullane Feb. 23 2018
- Silicon (Z=14) Si-XIV (12-11) 3521.1
  - Rate from ADAS
- Argon (Z=18) Ar-XVI (14-13)
  - Rate from ADAS





# Combined C-VI(8-7) C-VI(14-10) and Li-III (7-5) Being Used with Wide Wavelength Spectrometer











# Combined C-VI(8-7) C-VI(14-10) and Li-III (7-5) Being Used with Wide Wavelength Spectrometer



- By measuring both C-VI (8-7) and C-VI (14-10) on same sightline/spectrometer/CCD we can remove the C-VI contribution to emission at Li-III(14-10)
- Enables measurement of absolute lithium density
- This ratio  $B_{14-10}/B_{8-7} \approx 1/30$ 
  - Close to R. Bell 1/28 and is higher than expected using only n=1,2 donors

### NSTX Uses Dual Systems to Determine Li Density<sup>1</sup>




- The lithium-poloidal-CHERS (Li-pCHERS) spectrometers measure wavelength range 5145–5180 Å
- Second set of pCHERS view C-VI emission interleaved with the Li-pCHERS views
  - Views looking at the same portion of the plasma share the same optics
- 25% uncertainty in Li brightness
  - Major source of uncertainty is caused by the
     C-VI(14-10) transition
     1<sub>M. Podesta Nucl. Fusion 52</sub> (2012)






# Fluorine Has/Will be used for Impurity Confinement and Transport Studies

- Carbon tetraflouride (CF<sub>4</sub>) gas has been used for non-intrinsic non-recycling impurity
- LBO now injecting F from CaF2




Rate coefficients from M O'Mullane





# When Nitrogen is Injected into DIII-D the Deduced Nitron Density Appears Too High by Factor of Two

 N-VII(9-8) line at 5669.0 used, impurity profile measured and put into TRANSP runs for neutrons and stored energy








### By Scaling the Measured Nitrogen Density Before Running TRANSP we Estimate Density Error

- TRANSP first run with measured n profile shape
- Re-run with scale factors to determine best match
- When CER determined  $n_{N}$  profile is cut in half then neutron rate agrees
- Careful analysis by T. Osbrone matching neutrons and stored energy indicates this is generally true for Nitrogen
  - Is there something different about nitrogen than C, Ne?








### By Scaling the Measured Nitrogen Density Before Running TRANSP we Estimate Density Error

- TRANSP first run with measured n profile shape
- Re-run with scale factors to determine best match
- When CER determined  $n_{N}$  profile is cut in half then neutron rate agrees
- Careful analysis by T. Osbrone matching neutrons and stored energy indicates this is generally true for Nitrogen
  - Is there something different about nitrogen than C, Ne?








### Future/Conclusions

#### DIII-D is Upgrading CER for High-field Side Measurements





#### **Conclusions**

- NSTX and DIII-D are using the same n=1 and n=2 rate coefficients for C-VI(8-7)
- Both TFTR and DIII-D have determined ratio of C-VI  $B_{14-10}/B_{8-7}$  ≈ 1/28
  - Knowledge being used when determining Li density
- Concern over low energy NBI operation, n>2 processes, and inconsistencies with nitrogen data
- We expect to discuss these issues and make progress through this NB CRP in future RCMs





### Acknowledgement

This material is based upon work supported by the Department of Energy under Award Number(s) DE-FG02-95ER54309. **Disclaimer:** This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.



